

RECOMMENDED ADHESIVES



RECOMMENDED ADHESIVES

	Stick Vinyl Planks	Sheet	Rubber	Carpet Tile*	Axminster & Wilton	Needlepunch	Wovn Tiles
Ardex	AF172 (HS) AF545 (TC)	AF172 (HS) AF142 (HS)	AF172 (HS) AF545 (2P)	AF236 (PS)			
Holdfast	Holdfast 416 (HS) Holdfast 451 (TC)	Holdfast 416 (SPS) Holdfast 772 (HS)	Holdfast 451 (2P)	Holdfast 777 (PS) Holdfast 640 (PS) roll	Holdfast 104 (DSI) Holdfast 108 (DSI)		Holdfast 416 (SPS) Holdfast 772 (HS) Holdfast 777 (PS)
Mapei	Ultrabond VS90 plus (HS) Ultrabond Eco V4SP (HS) Ultrabond EcoV4 Evolution Ultrabond MS 4 LVT Wall*	Ultrabond VS90 plus (HS) Ultrabond Eco V4SP Ultrabond EcoV4 Evolution	Ultrabond V4SP (HS) Ultrabond VS90 plus (HS) Adesilex G19 (2P) Ultrabond MS 4LVT (TC)	Ultrabond Eco fix (PS)*	Ultrabond Eco170 (DSI)	Ultrabond Turf (OD) Ultrabond Eco V4SP (DSI) Ultrabond Eco 170 (DSI)	Ultrabond Eco Fix* Ultrabond Eco 380 Ultrabond Eco V4SP Ultrabond Eco V4 Evolution Ultrabond Eco VS90 Plus Ultrabond Eco MS 4 LVT Wall*
MJS	MJS Enviro 2012 (HS)	MJS Maxbond 107 (SPS) Enviro 2007 (SPS) Enviro 2012 (HS)	MJS Maxbond MPU (2P) MJS Enviro 2012 (HS)	MJS Enviro 2009 (PS)	Enviro 2010 (HS)	MJS 006 (OD)	MJS Enviro 2012 (HS)
Nexus	NA870 (HS)	NA820 (SPS) NA870 (HS)	NA870 (HS) TBC NA560 (2P)	NA840 (PS)	Nexus 910 (HS)	Nexus 485 (OD)	NA870 (HS)
RLA	RLA GS220 (HS) Polymer 265 (HS) Polymer 365 (HS)	RLA GS220 (HS) Polymer 265 (HS) Polymer 365 (HS)	RLA 1718 (2P)	RLA GS300 (PS) RLA GS444 (PS) Polymer 999 (PS)	Polymer 300 (DSI)		RLA GS220 (HS) RLA GS300 (PS) Polymer 265 (HS) Polymer 365 (HS)

*Must use U1 trowel

RECOMMENDED ADHESIVES

	Stick Vinyl Planks	Sheet	Rubber	Carpet Tile*	Axminster & Wilton	Needlepunch	Wovn Tiles
Roberts	Roberts 200 (HS) Roberts 285 (HS) Roberts 280 HT (HS) Roberts 555 (2P)	Roberts 200 (HS) Roberts 285 (HS) Roberts 555 (2P)	Roberts 555 (2P)	Roberts 656 (PS) Roberts 585 (PS)	Roberts 95 (DSI) Roberts 59 (DSI) Roberts 100 (DSI) Roberts 85 (DSI)	Roberts 6037 (OD) Roberts 85 (DSI)	Roberts 200 (HS) Roberts 285 (HS)
Uzin	2000SE (HS) KE66 (HS) KR430 (TC)	2000SE (HS) KE66 (HS) KR430 (TC)	KE66 (HS) KR430 (TC)	U500 (PS)	UZ57 (DSI)	UZ57 (DSI) KE2000S (DSI)	2000SE (HS) KE66 (HS)

* All pressure sensitive adhesives MUST be applied with a V1 trowel for cushioned backed carpet tiles.

Substrate porosity and environmental factors will have an effect on the open time of adhesives, please ensure all adhesives are applied as per manufacturer's instructions, ensuring correct spread rates and transfer. Failure to comply may affect any warranty conditions.

For further technical information please contact adhesive manufacturer.

Ardex	1800 224 070	Mapei	07 3276 5000
RLA	1800 242 931	Uzin	0419 169 925
Holdfast	1800 242 931	MJS	0438 424 949
Roberts	1800 242 931	Nexus	03 9706 4022

(PS) Pressure Sensitive **(SPS)** Semi Pressure Sensitive **(HS)** Hard Set **(TC)** Total Cure **(2P)** Two Component **(OD)** Outdoor **(DSI)** Direct Stick Indoor

Recommended Adhesives

Document ID: 100044

Revision No: 05

Date modified: 17/09/2021

Signature Floorcoverings Pty Ltd
ABN 45 007 172 938
PO Box 1122 Epping 3076 VIC
13 Wurundjeri Drive, Epping 3076 VIC Australia
Tel: 03 9401 0888 Fax: 03 9401 0866
www.signaturefloors.com.au

PO Box 12521, Penrose 1642, Auckland
Unit A, 698 Great South Road, Penrose 1060, Auckland
Tel: 0800 150 555
www.signaturefloors.co.nz

