INSTALLATION GUIDELINES

PLANTINO NEXIS - WET AREAS





PLANTINO NEXIS – WET AREAS INSTALLATION GUIDELINES

FOR BATHROOM, KITCHEN & LAUNDRY ROOM INSTALLATIONS

Nexis Laminate Flooring has Atroguard water resistant technology and may be installed in wet areas Including Kitchens, Bathroom and Laundry rooms providing areas do not have waste/overflow drains subject to local building codes. Nexis Laminate Flooring may not comply with some regulatory requirements for waterproofing in identified wet rooms.

- Nexis is not suitable to be installed in pool areas, saunas or shower recesses.
- It is important to seal any cut planks to ensure superior and warranted performance. When a flooring plank is cut to fit (either end cuts or side cuts), a sealant is always required around the perimeter of the installation.

- Installations where the flooring planks continue from other areas, the use of a transition trim is required to create a separate raft. Accommodating a 10mm gap between the planks and the adjoining area.
- Fill the expansion spaces with a 10mm compressible PE foam backer rod and cover with a flexible 100% silicone sealant to the entire perimeter of the installation. Do not use an acrylic sealant.
- Prior to installing mouldings, apply silicone sealant to the portion of the moulding or transition that will contact directly with the flooring surface.
- Install moulding's and immediately wipe away any excess silicone sealant.
- Apply silicone sealant at connections to doorframes or any other fixed objects.
- Branded and generic silicone tubes are available in any local home centre or hardware location.

Plantino Nexis - Wet Areas - Installation Guidelines

Document ID: 100064.5 Revision No: 01 Date modified: 28/02/2023

Signature Floorcoverings Pty Ltd ABN 45 007 172 938 PO Box 1122 Epping 3076 VIC Australia 13 Wurundjeri Drive, Epping 3076 VIC Australia Tel: 1800 150 554 www.signaturefloors.com.au

15 Bath Street, Parnell Auckland 1052 New Zealand Tel: 0800 150 555 www.signaturefloors.co.nz